www.pjwmeters.com



## **Secure Smart Meter Sprint 211 Installation Procedure**

NOTE: For full commissioning instructions please refer to the Sprint 211 installation guide.

- 1. Carry out a full Risk Assessment of the property and meter position.
- 2. Following your Code of Practice, exchange the electricity meter with the Smart E-Meter (Sprint 211) and energise.
- 3. With the customer's permission, install the IHD in the agreed location within the property (if required)
- 4. Begin the commissioning process by pressing the LH button on the meter for 5 seconds.



Followed by



5. To select all phases, press RH button.



6. Then Press RH button to confirm.



Followed By



## 7. Switch test: Press LH button



Followed by Supply Off



Followed by



Followed By supply on



This Process is repeated for the AUX Switch



Followed by



Followed by





Followed by



Followed by



8. Sim Registration:



Followed by



Note: The meter displays the setting of antenna type and signal strength.

9. Press LH button to test the signal strength inside the meter box.



10. Press LH button on meter and close the metal meter cabinet door.



11. There will be a 30 second countdown timer whilst the signal strength with the door closed.





- 12. The signal strength with the door closed will be displayed
- 13. Press the RH Button to move to Step3.



Followed by



Followed by



Note: At this stage the HAN antenna type can be selected by pressing the LH button.

14. If antenna type is correct press the RH button.



15. Press LH button to end commissioning.



Followed by



16. Once installed the AUX switch LC1 are active as specified by the tariff.